

Fire Department

Operation of the FSK-T in case of a fire alarm

In case of a pending alarm:

- Insert the FD key into the FD lock and turn it to the right
- Pull the door open at the bow-shaped handle
- Activated key (LED button illuminated)
- Remove the key by pressing the LED button; then turn the key to the left (remove)

Extended release:

- Insert the FD key into the internal FD lock and turn it to the right (hold)
- All non-activated keys are permanently illuminated
- Remove the keys by pressing the LED button

Return (with the door open):

- Insert the key into the cylinder and turn it to the right

Return (with the door closed):

- Insert the FD key into the FD lock and turn it to the right (up to the stop, hold)
- Pull the door open at the bow-shaped handle
- Insert the key into the cylinder and turn it to the right

Buzzer:

- End of acoustic signal following return of all keys

Attention!

Following reset of the central fire alarm system (BMZ), no key removal is possible anymore. If required, a new fire alarm would have to be triggered.